



Hydrometer for batteries

- 1| Nahita battery hydrometer is ideal for checking, in a safety way, the charge level of automobile batteries by determining the electrolyte density.
- 2| It consists of a small hydrometer placed inside a wider tube, one

- of whose ends is joined to a rubber bulb while the other end is narrower to be introduced into the cells of the battery.
- 3| By a simple suction mechanism, the electrolyte fills the tube and its density is then shown by the hydrometer.



Code	Range	Divisions
KL020	1100-1300 g/mL	5