



1 | These portable pH meters are specially designed for use in swimming pools, fish farms, water treatment, agriculture and any application requiring fast, accurate, on-site pH measurement.

2 | Measurements are made by means of a pH electrode incorporated in the instrument and are displayed on a digital display. To ensure accurate pH determinations they can be easily calibrated at two points.

Pen-type pH meter



- 1 | Buttons for:
 - Power ON/OFF
 - CAL button for calibration
- 2 | Includes carrying case, manual and 3 sachets of pH 4.01, 6.86 and 9.18 pH buffer solutions.
- 3 | Calibration of acidic or basic pH range. 3-point calibration

Code	KDB003
Display	LCD
Probe type	Precision glass bulb electrode
Range	0.00 – 14.00 pH
Resolution	0.1 pH
Accuracy	± 0.5 pH
Power supply	2 x 1.5V button cell batteries type LR44 (<i>included</i>)
Dimensions	155 x 29 x 16 mm.