

Medical / Spectacles / 5X7 MED

## 5X7 Med - Clear Plus

Code: RBG016

Date: 29-01-26 1/2

5X7 MED is designed for a perfect integration with prescription glasses. The exclusive SoftPad technology, a high-strength insert combined with rod adjustments, ensure maximum stability even in extreme conditions.



## Frame mark (EU)

Mod.5X7 U EN166 FT U EN175 FT CE

## Lens mark (EU)

2C-1.2 U 1 FT K N CE

## Frame technology

Overspec, Adjustment of temples in length, Rubber Terminal, Terminal tilting movement, SoftPad

## Conditions of use

Standard brightness, Low brightness

## Lens technology

Anti-Scratch + Anti-Fog (KN - Vanguard PLUS), UV400

## Lens color

Clear

## Lens material

Polycarbonate

## Frame color

White/Blue

## Standards

EN166, EN170

## Scale number

(2C-1.2)

## Mechanical resistance

Low energy impact (F)

## Optional requirements

Resistance to surface damage by fine particles (K), Resistance to fogging of oculars (N), Protection against high speed particles at extreme temperatures -5°/+55° C (T)

## Optical class

Optical class (1)

## Weight

37g

<https://www.auxilab.es/en/laboratory-equipment/safety-eyewear-5x7-anti-scratch-anti-fog-plus/>



01.

**UPPER FRONTAL**

Grants comfort and stability with a shockproof effect

02.

**SIDE SHIELDS**

Improved peripheral protection even in combination with eyeglasses

03.

**RUBBER TERMINAL WITH TILTING MOVEMENT**

Allows glasses to adhere to the temples for a perfect grip

04.

**LENGTH ADJUSTMENT**

Allows to obtain the correct fit and work in constant safety

Attention! Any images on this page illustrate the frame technologies of the product family in question and may represent frame and lens colours that do not correspond to the product code of the following sheet.