

# Max/min digital thermometer with metal probe

Code: KJJ004

## PRODUCT FEATURES

Temperature measurement:  $-50^{\circ}\text{C}$  -  $+300^{\circ}\text{C}$   
( $-58^{\circ}\text{F}$  -  $+572^{\circ}\text{F}$ )

Temperature accuracy:  $\pm 1^{\circ}\text{C}$  /  $^{\circ}\text{F}$

Power-saving mode: 10 minutes auto power off function

Power supply: 1.5V (AG13) x 1

Function of the keys:

1. ON/OFF key: switching
2.  $^{\circ}\text{C}$  /  $^{\circ}\text{F}$  key: in the display mode, this button can be  $^{\circ}\text{C}$  /  $^{\circ}\text{F}$  conversion function
3. HOLD key: when pressed, the LCD display can be maintained at HOLD state; when pressed again, the display shows the actual temperature value
4. MAX/MIN key: to view the maximum/minimum temperature

# Termómetro max/min digital con sonda metálica

Ref: KJJ004

## CARACTERÍSTICAS

Rango de temperatura:  $-50^{\circ}\text{C}$  -  $+300^{\circ}\text{C}$   
( $-58^{\circ}\text{F}$  -  $+572^{\circ}\text{F}$ )

Precisión:  $\pm 1^{\circ}\text{C}$  /  $^{\circ}\text{F}$

Modo de ahorro de energía: función de  
apagado automático en 10 minutos

Alimentación: 1.5V (AG13) x 1

Función de los botones:

1. ON/OFF: encender/apagar
2.  $^{\circ}\text{C}$  /  $^{\circ}\text{F}$ : convierte de  $^{\circ}\text{C}$  a  $^{\circ}\text{F}$  y viceversa
3. HOLD: cuando se pulsa, la lectura mostrada en pantalla se congela; si se pulsa de nuevo, se mostrará la temperatura real medida
4. MAX/MIN: permite visualizar la temperatura máxima/mínima